

	<b>Function options</b>		Description	Application Notes
JP1		HWS	Open, Stop & Close	
		OP/CL	Open & Close only	
JP2	Auto Close	30 Second	Gate auto close after	
			remained open for 30	
			seconds	
		Off	Select if function not required	
JP3	Open Reverse	On	Open Revese enabled	When enabled, the movement
		Off	Open Revese disabled	of the gate is first reversed, then open
JP4	Light	Follow	Light status & motor movement in parallel	Light is on when motor is on, light is off when motor is stopped
		Delay	Light status is set to be off after a delay of 60 seconds	When gate is closed, light will be off after 30 seconds
JP5	Soft Start	On	Soft Start enabled	Firmware Run at 3speed
		Off	No Soft Start function	Slow $\rightarrow$ Fast $\rightarrow$ Slow